

01 03 05 07 09 11 13 15 17 19 21 23 25 27 29 31 33 35 37 39

A

B

C

D

E

LES MODES DE FONCTIONNEMENT
FEUILLE DE DEFINITION DE MESSAGES XBT

N MESS.	TEXTE MESSAGES	NUMERO COLONNE	NUMERO LIGNE	CLE D'ACCES	COEFIC. CONVERS.	VARIABLE AUTOMATE
001	AV. CHARIOT PU1	00	01	1	1	830
002	RC. CHARIOT PU1	00	01	1	1	831
003	AV. MEULE PU1	00	01	1	1	832
004	RC. MEULE PU1	00	01	1	1	833
005	MARCHE MEULE PU1	00	01	1	1	834
006	M. ASPIRATEUR PU1	00	01	1	1	835
007	AV. CHARIOT PU2	00	01	1	1	840
008	RC. CHARIOT PU2	00	01	1	1	841
009	AV. MEULE PU2	00	01	1	1	842
010	RC. MEULE PU2	00	01	1	1	843
011	MARCHE MEULE PU2	00	01	1	1	844
012	M. ASPIRATEUR PU2	00	01	1	1	845
013	RAZ COMPTEUR	00	01	1	1	846
014	DEMANDE COMPTEUR	00	01	1	1	847
015	ACQUIT DEF AUT	00	01	1	1	848
016	ST #3 - MEULE MIN.	00	01	2	1	B 212
017	MARCHE MANUELLE	00	01	1	1	
018	MARCHE REGLAGE	00	01	1	1	
019	MARCHE AUTO	00	01	1	1	
020	DEF AUT AIR	00	01	1	1	
021	DEF. MEULE 1 PU1	00	01	1	1	
022	DEF. MEULE 2 PU1	00	01	1	1	
023	DEF. ASP. 1 PU1	00	01	1	1	
024	DEF. MEULE 1 PU2	00	01	1	1	
025	DEF. MEULE 2 PU2	00	01	1	1	
026	DEF. ASP. 2 PU2	00	01	1	1	
027	DEF. ORIGINE PU1	00	01	1	1	
028	DEF. ORIGINE PU2	00	01	1	1	
029	ARRET D'URGENCE	00	01	1	1	
030	CPT BON	00	01	1	1	W0050
031	CPT MAUV.	00	01	1	1	W0051

A

B

C

D

E